
Radio System , (8DN),(8DP),(8DS)

From September 2014




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





Information Electronics Control Module 1


- J285 Instrument Cluster Control Module
- J533 Data Bus on Board Diagnostic Interface
- J794 Information Electronics Control Module 1
- SF3 Fuse 3 (On Fuse Panel F)
- ST3 Fuse Panel 3
- ST4 Fuse Panel 4
- SF7 Fuse 7 (On Fuse Panel F)
- T2aq 2-Pin Connector
- T2aw 2-Pin Connector
- T2bm 2-Pin Connector
- T8f 8-Pin Connector
- B318 Positive Connection 4 (30a) (in Main Wiring Harness)
- (B607) Connection 3 (in Interior Wiring Harness)
 - Refer to Applicable Wiring Diagram for Fuse Positions
- *2 Refer to Applicable Wiring Diagram for Data Bus Networking
- *3 For Vehicles with Bose Sound System
- *4 Fiber Optic Cable
- *5 For Vehicles with CD Changer
- *6 For Vehicles Without Noise Reduction






Multimedia System Control Head, Instrument Cluster Control Module, Information Electronics Control Module 1, Display Pivot Mechanism

- E380 Multimedia System Control Head
- E506 Display Unit Button
- J285 Instrument Cluster Control Module
- 1519 Vehicle Electrical System Control Module
- J794 Information Electronics Control Module 1
- Γ6q 6-Pin Connector
- T8o 8-Pin Connector
- 8p 8-Pin Connector, Behind the Left Front Center Console
- T17h 17-Pin Connector, In the Left A-Pillar Connector Station
- T20b 20-Pin Connector
- T32 32-Pin Connector
- T32c 32-Pin Connector
- V301 Display Opening/Closing Motor
- VX452 Display Pivot Mechanism
 - 99 Ground Connection 3 (in Instrument Panel Wiring Harness)
- (373) Ground Connection 8 (in Main Wiring Harness)
- A175 Connection 58s (in Instrument Panel Wiring Harness)






Information Electronics Control Module 1. Control Module for Emergency Call Module and Communication Unit, Microphone Unit in Front Roof Module

- J525 Digital Sound System Control Module J533 Data Bus on Board Diagnostic Interface Rearview Camera System Control Module Information Electronics Control Module 1 Peripheral Camera Control Module J949 Control Module for Emergency Call Module and Communication R140 Left Front Microphone R141 Right Front Microphone R164 Microphone Unit in Front Roof Module R321 Emergency Call Module Microphone 6-Pin Connector T12c 12-Pin Connector
- T32b 32-Pin Connector
- **OBD Connection 1 (in Main Wiring Harness)**

T12d 12-Pin Connector

- Depending on Equipment Refer to Applicable Sound System Wiring Diagram
- For Vehicles with Emergency Call Module



Front Information Display Control Head, Information Electronics Control Module 1

J685 Front Information Display Control Head J794 Information Electronics Control Module 1

T4de 4-Pin Connector

T4df 4-Pin Connector T8ag 8-Pin Connector


8ag 8-Pin Connector

45 Ground Connection Behind Instrument Panel, Center

213 Ground Connection (in Instrument Panel Wiring Harness)

* For Vehicles with CD Changer





J794 (T4ab T2ax T2ax T12d /12 15 103 0.35 0.35 rt/gn B478 0.35 rt/vi 0.35 rt/gn T4y 11/1 T4y T4y rt/gn 0.35 0.35 0.35 0.5 0.35 T2bt V2 T2ar V2 T2bt T2bw V1 T51 V2 T2ar R11 R183 R24 R112 R₁₂₆ [4G.I-110080420]

Information Electronics Control Module 1, Antenna Amplifier, Antenna Amplifier 3, Telephone Baseplate

J794 Information Electronics Control Module 1

R11 Antenna

R24 Antenna Amplifier

R112 Antenna Amplifier 3

R126 Telephone Baseplate

R183 Digital Radio Antenna

T2ar 2-Pin Connector

T2ax 2-Pin Connector

T2bt 2-Pin Connector

T2bw 2-Pin Connector

T4ab 4-Pin Connector


T4y 4-Pin Connector, Near the Telephone Baseplate

T5I 5-Pin Connector

T12c 12-Pin Connector

T12d 12-Pin Connector

B478 Connection 14 (in Main Wiring Harness)



ws = white sw = black

ro = red

rt = red

br = brown
gn = protected by copyright. Copying for private or commercial purposes, in part or in whole, is not
green
gr

blue with respect to the correctness of information in this document. Copyright by AUDI AG.
 grey

gr = grey li = lilac


vi = lilac

ge = yellow or = orange

rs = pink

J₇₉₄ €





ws = white
sw = black
ro = red
rt = red
br = brown
gn = green
bl = blue
gr = grey
li = lilac
vi = lilac
ge = yellow
or = orange
rs = pink

4G.I-110090420

Information Electronics Control Module 1, Cellular Telephone Amplifier

J794 Information Electronics Control Module 1

R86 Cellular Telephone Amplifier


T2dc 2-Pin Connector T2dd 2-Pin Connector T4az 4-Pin Connector

50 Ground Connection in Luggage Compartment, Left

382 Ground Connection 17 (in Main Wiring Harness)

Not for USA

*2 For Vehicles with Cell Phone Preparation



Information Electronics Control Module 1, External Audio Source Connection

- J794 Information Electronics Control Module 1
- R199 External Audio Source Connection
- T12e 12-Pin Connector
- T30b 30-Pin Connector
- For Vehicles with External Audio Source Connection Audi Music Interface

= white = black = red = red

= brown = green = blue = grey = lilac

= lilac = yellow

= pink

or

rs

= orange

J794 (¥T4z /1 0.14 126 otected by copyright. Copyling for private or commercial purposes, in part or in whole, is not ermitted inless a horised y AUDI AG. AUDI AG does not guarantee or accept any liability with respect to t ess of information in this document. Copyright by AUDI AG. 1.0 0.5 T30b /22 T30b V16 T30b /17 R199 128 129 131 132 133 134 137 138 139 [4G.I-110110420]

Information Electronics Control Module 1, External Audio Source Connection

J794 Information Electronics Control Module 1

R199 External Audio Source Connection

T4z 4-Pin Connector T30b 30-Pin Connector

= white = black = red = red

= brown = green

= blue = grey = lilac


= lilac = yellow

= pink

or

rs

= orange



Information Electronics Control Module 1, External Audio Source Connection

J794 Information Electronics Control Module 1


R199 External Audio Source Connection

T6cq 6-Pin Connector

T12e 12-Pin Connector

For Vehicles with External Audio Source Connection - AUX-IN Connection

*2 For Vehicles with Passive Speakers



- R41 CD Changer
- Fuse 1 (On Fuse Panel C)
- Fuse Panel 1
- Fuse 2 (On Fuse Panel B)
- Fuse 2 (On Fuse Panel C)
- ST2 Fuse Panel 2
- T2as 2-Pin Connector
- 8-Pin Connector
- T17g 17-Pin Connector, In the Left A-Pillar Connector Station
- B159 Diagnostic Connection (in Interior Wiring Harness)
 - Refer to Applicable Wiring Diagram for Fuse Positions
- For Vehicles with CD Changer
- Fiber Optic Cable
- Refer to Applicable Wiring Diagram for Data Bus Networking